

Direct Connectivity For Digital Signage

With DSMAP you can connect to and manage a Digital Signage Player anywhere in the world as long as you have Internet connectivity. No fixed IP required, No Firewall changes, No Router configuration, No network address translation and no port forwarding.

No VPN required

DSMAP removes the need to run a VPN.

Full direct connectivity to your player device

With DSMAP you can connect to your player and transfer data and manage the device.

Always-on Connection

The DSMAP connection is automatically established and maintained by the DSMAP client.

Web Management Interface

DSMAP client configuration is managed via web interface with detailed reporting on connection status and bandwidth usage.



1

Install the agent and enrol your player on the DSMAP network using a unique Identifier.



2

Your player will automatically connect to the DSMAP network using it's Internet connection.



3

You can now connect to your player and distribute content, manage the device and most importantly - know exactly how your network is performing.

For more information and a free 15 day trial, please visit www.dcmidiads.com



**Central Point
Communications**

Contact

Central Point Communications (Pty) Ltd.
Unit 10, The Gardens Office Park
Afejee street, Randpark Ridge
2125

Telephone: +27 11 794-4550
Email: info@dcmidiads.com

Distribution in North America

The Digital Signage Group
19462 Powder Hill Place Suite 101
Poulsbo
WA
98370
Telephone: +1866.591.1974 Ext.298
Email: jillm@tdsg.net